







- Ⓛ Montage- und Bedienanleitung
- Ⓝ 安裝及操作指南
- Ⓒ Návod k instalaci a k použití
- ⓔ Instrucciones de montaje y de manejo
- ⓕ Instructions de montage et mode d' employ
- ⓖ Installation and operating instructions
- ⓖ ΟΔΗΓΙΕΣ ΕΓΚΑΤΑΣΤΑΣΗΣ ΚΑΙ ΣΥΝΤΗΡΗΣΗΣ
- ⓗ Szerelési és használati utasítás
- ⓙ Istruzioni di montaggio e per l'uso
- Ⓝ Montagehandleiding en Gebruiksaanwijzing
- Ⓟ Instrukcja montażu i obsługi
- Ⓡ Instrucțiuni de montaj și utilizare
- Ⓡ Руководство по монтажу и эксплуатации
- Ⓚ Návod na montáž a obsluhu




1.





2.






	<b>1</b>	<b>2</b>	<b>3</b>
53 811	G 3/4	80 - 110mm	max Ø55mm

1.





2.






	<b>2</b>	<b>3</b>
29 757	60 - 110mm	max Ø55mm

1.



2.



	<b>2</b>	<b>3</b>
29 747	60 - 110mm	max Ø55mm